

INSTALLING WINDSHIELD SEAL ON TO THE WINDSHIELD FRAME.

Fits: 48-7003110 1935-36 Car & Pickup

- STEP # 1 Remove windshield frame from car and be sure to clean all old rubber out of the groove.
- STEP # 2 Find the bonded ends of the windshield (rubber) seal and start the rubber into the groove of windshield frame at the bottom center.

Push rubber into the groove at the same time slightly stretching the rubber as it goes into the groove section of frame and work rubber in as you go around the frame.

