

78-7243720

1937 COUPE
2 DR. SEDAN AND
4 DR. SEDAN
TRUNK SEAL



www.dennis-carpenter.com

Installing Trunk Seal

Remove the trunk lid from the vehicle.

Remove all of the old trunk seal and residual glue.

Clean the surface with Wax and Grease Remover

Use 3M no.08008 black adhesive. Apply per instructions as labeled on the tube.

Place the joint of the seal at the bottom of the trunk lid. (near the latch)

Clean up excess adhesive using Wax and Grease remover.

DENNIS CARPENTER FORD REPRODUCTIONS 4140 Concord Parkway So., Concord, NC 28027 704-786-8139

MFG. U.S.A. A HIGH QUALITY PRODUCT FROM
DENNIS CARPENTER 704-786-8139