

8A-18809-S
RADIO FACE
INSTALLATION INSTRUCTIONS

1. TO REMOVE CHROME FACE PLATE FROM RADIO – REMOVE FOUR SCREWS MARKED 'A' ON DIAGRAM
2. TO REMOVE RETAINERS HOLDING PLASTIC INSERT – LOOSEN TWO NUTS MARKED 'B' ON DIAGRAM
3. IF NEEDED – FILE SMALL AMOUNT OFF OF TOP OF INSERT MARKED 'C' ON DIAGRAM
4. ALIGN PART 'C' WITH PART 'D' AND PLACE IT IN CHROME RADIO FACE

