

PART NUMBER KA8300
1949-51 TREE RIBBED FENDER SKIRTS
INSTALLATION INSTRUCTIONS

- 1.) MOUNT CLAMPS TO FENDER SKIRTS LEAVING NUTS AND BOLTS LOOSE
- 2.) OPEN LOCKING HANDLE
- 3.) HOLD SKIRT UP TO CAR BODY
- 4.) SLIDE BOTTOM OF SKIRT CLAMPS UNDER BOTTOM ROLL OF CAR BODY
- 5.) PUSH TOP OF SKIRT INTO WHEEL OPENING
- 6.) OPERATE LOCKING HAND
- 7.) TIGHTEN SCREWS ON BOTTOM OF SKIRT

