

**1956 FORD PICK-UP AND COMMERCIAL INSTALLATION
INSTRUCTIONS FOR WINDOW CRANK SHAFT REPAIR KIT**

B6C-8123205-S

To remove the old window crank shaft assembly, drill out the three rivets holding the retainer in place. Replace the old shaft with the new one from the window crank repair kit. The retainer can now be put back in place and secured with three short steel pop rivets. Use grease as required. (Recommend white lube.)

