


# 1957-1972 Ford Truck Windshield / Rear Window Seal Installation


WINDOW OPENING FLANGE



## NOTE

It is recommended to use an auto glass sealer when installing the new rubber window seals to prevent possible leaking. Permatex Auto Glass Sealer 7651259 is one example.

REAR WINDOW RUBBER SEAL




## Installing windshield rubber seal

1. Remove all old weather stripping and weather stripping sealer from the windshield opening flange.
2. Apply a continuous bead of sealer to the windshield opening flange. Apply a continuous bead of sealer into the glass crevice of the rubber seal then install the weather strip onto the glass.
3. Apply a soap/water solution to the flange area of the weather strip, then install a draw cord into the flange crevice of the weather stripping. Allow about 12 inches overlap at the top center.



PULL DRAW CORD

RUBBER SEAL



WINDOW OPENING FLANGE


PULL DRAW CORD

RUBBER SEAL

4. Position the glass assembly in the opening and have a helper apply pressure to the outside of the glass. From the inside, begin pulling the draw cord. This procedure allows the weather stripping to be pulled over the flange area. Alternate from side to side when pulling the cord to keep the installation even.

## Installing rear window rubber seal

1. Remove all old weather stripping and weather stripping sealer from the rear window opening flange.
2. Apply a continuous bead of sealer to the rear opening window flange. Apply a continuous bead of sealer into the glass crevice of the rubber seal then install the weather strip onto the glass.
3. Apply a soap/water solution to the flange area of the weather strip, then install a draw cord into the flange crevice of the weather stripping. Allow about 12 inches overlap at the top center.



Flange crevice of rubber seal

Glass

Draw cord

Install draw cord into flange crevice of rubber seal around entire window.

4. Position the glass assembly in the opening from the inside and have a helper apply pressure to the inside of the glass. From the outside, begin pulling the draw cord. This procedure allows the weather stripping to be pulled over the flange area. Alternate from side to side when pulling the cord to keep the installation even.



## HELPFUL TIPS

Use masking tape to temporarily hold the seal onto the glass before installing the window. After the window has been installed the tape can be removed.



4140 Concord Parkway So., Concord, NC 28027  
(704) 786-8139 email: info@dennis-carpenter.com  
www.dennis-carpenter.com