

1961-67 Econoline Van Rear Door or Side Door Seal Installation



HELPFUL TIPS

BEFORE APPLYING WEATHER STRIPPING

Experience has shown us that taping the door seal into position before any adhesive is applied allows you to check the fit of the seal and to make any door adjustments if necessary.

Apply the adhesive to the door, not the seal. Glue around the door as described in the instructions.

The best (and cleanest) results comes from glueing a 12" to 18" section of the door at a time, applying the weather stripping then taping it into position before continuing onto the next 12" to 18" section.

After the adhesive has had ample time to cure the tape can be removed.

INSTALL DOOR SEALS

NOTICE: There are part numbers molded into the corners of the rubber seals for reference

- 1 Remove the old door seals and glue material from the doors. Clean doors thoroughly where the seals are to be adhered. A degreaser/ wax remover solution is recommended.
- 2 Determine the left and right door seals.
- 3 With the doors open, begin on the driver's side door with the molded end of the door seal (marked as C1UZ-8925315-LTC) on the top corner of the door by inserting the tab of the molded end into the slot on the door.
- 4 Glue the seal across the top of the door to the corner, down the hinge side to the bottom corner then across the bottom of the door until you reach the opposite bottom corner.
- 5 Finish by pushing the tab of molded end (C1UZ-8925310-LLC) into the slot located on the door.
- 6 Begin on the passenger's side door by glueing inside corner (hinge side) with molded corner (C1UZ-8925320-RTH), continue glueing down the hinge side of the door to the molded corner (C1UZ-8925305-RLH)
- 7 Glue the seal across the bottom of the door to molded corner (C1UZ-8925309-RCL) then up the latch side of the door to the upper corner (CODZ-8925309-RCL). Finish glueing across the top of the door.

NOTE: It is necessary to use a weather stripping adhesive in order to install door seals. Dennis Carpenter Ford Reproductions recommends and sells 3M brand Weather Stripping Adhesive. Our part # is COAZ-19554-A

DRIVER SIDE DOOR BEGIN HERE

Insert tab of molded end
C1UZ-8925315-LTC
into slot on door

PASSENGER SIDE DOOR BEGIN HERE

Begin with molded corner
C1UZ-8925320-RTH

Insert tab of
molded end
C1UZ-8925310-LLC
into slot on door

corner
C1UZ-8925305-RLH

corner
C1UZ-8925309-RCL

VIEWED WITH BACK DOORS OPEN



4140 Concord Parkway So., Concord, NC 28027
(704) 786-8139 email: Info@dennis-carpenter.com
www.dennis-carpenter.com